



# Fujifilm FinePix S1 Battery Replacement

Replace your battery to get your camera to turn on.

Written By: Brandon Benavente



## INTRODUCTION

Following this guide will involve the very easy changing of the battery for your camera.

## Step 1 — Battery



- Release the slide on the battery cover and open the hatch.

⚠ Make sure camera power is OFF.

## Step 2



- Pull back on the orange battery release clip and allow the battery to pop up.

## Step 3



- Remove the battery from the camera.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 09:12:50 AM.